



Note: Cut panel facings to place HD type anchor, post and 2X plate. Use expanding foam to fill in area around hold down anchor. Insulate cavity with low expanding foam. Replace OSB facing and nail to 2X blocking.

SECTION

Scale: NTS

Updated 1-16-12

R-Control® SIP

TITLE:

Post to Concrete Anchorage

NO.

SIP-136a