

## R-Control Do-All-Ply and SIP Tape

- 1.) Make certain surfaces are clean, dry, and free of dirt and foreign materials prior to placement of R-Control Do-All-Ply or SIP Tape.
- 2.) Store R-Control Do-All-Ply and SIP Tape in a warm area prior to installation during cold weather.
- 3.) Place R-Control Do-All-Ply in straight CONTINUOUS 1/2 in. diameter beads as shown in details.
- 4.) Place R-Control SIP Tape at joints between SIPs as shown in details.
- 5.) After SIP Tape installation, use a hard roller to apply pressure to the SIP Tape surface to promote adhesion.
- 6.) Apply SIP Tape or equivalent vapor retarder on interior or exterior of SIP per climate conditions or code requirement.
- 7.) Refer to R-Control Do-All-Ply and SIP Tape material safety data sheets.

NOTE: It is the responsibility of the installer to apply R-Control Do-All-Ply and R-Control SIP Tape properly.

Failure to install R-Control Do-All-Ply and R-Control SIP Tape in accordance with instructions and as shown in details will reduce the durability of the SIP structure.

Updated 1-16-12

R-Control® SIP

TITLE:  
Do-All-Ply and SIP Tape

NO.  
SIP-101